



## Firmware Update VIASS Pro2

1. Download the last version of VIESW2 Software from [www.viass.at](http://www.viass.at)  
[https://www.vi-shooting.com/1/soft/VIESW2\\_last.zip](https://www.vi-shooting.com/1/soft/VIESW2_last.zip)
2. Extract the Zip file to c:\viesw2
3. Install driver ( only for the first installation)  
Go to the folder C:\VIESW2\driver  
and start the driver installation: **CDM21228\_Setup.exe**
4. Connect the VIASS Pro2 to the USB Port
5. Start the configuration Tool VIESW2




select your COM Port from the device, and click Connect

6. First you must delete the **old** Firmware



1: delete the old Firmware

The Firmware is now deleted




Reset

you can see NO Firmware

If you not see this Window, press Reset Button and wait.


7. Select the new Firmware and press Firmware Upload



select new Firmware

Firmware Upload

8. After upload the Firmware, please press **READ VIASS**



You can see the new Firmware in this Window. Disconnect the VIASS from the PC. Finish  
 If you have problems, please contact us: [office@viass.at](mailto:office@viass.at)